


Pololu Jrk Configuration Utility

Pololu Jrk Configuration Utility - Plots of Variables vs. Time



- Input: 0 - 4095
- Target: 0 - 4095
- Feedback: 0 - 4095
- Scaled feedback: 0 - 4095
- Error: ± 4095
- Integral: ± 1000
- Duty cycle target: ± 600
- Duty cycle: ± 600
- Current (mA): ± 5000

Pause Run Range (%): -100 - 100 Time (s): 5

Reload settings from device Stop Motor Run Motor Apply settings to device