



This is the Script you sent me inserted before the instruction 6 ### sequence sobroutines: ###

Fig. 12

File Device Edit Help

Connected to: Not Connected Connection to Maestro #00197868 lost.

Error code: N/A

Status Errors Channel Settings Serial Settings Sequence Script

Code Run script on startup

Script: 209 of 8192 bytes used

Subroutines: 0 of 126 levels used

Stack

```

1 begin                #start loop
2   6 get_position 500 less_than if #check if the button on channel 6 is pressed
3     demo_1            #if it is, run your Demo_1 subroutine
4   endif
5 repeat              #repeat script
6   ### Sequence subroutines: ###
7
8   # Demo 1
9   sub Demo_1
10    500 5480 6914 5945 5363 5848 7185
11    0 0 0 0 0 frame_0..5_7..11 # Frame 0
12    500 4452 6080 6488 6294 5596 5228 frame_0..5 # Frame 1
13    500 6701 6798 5324 4704 5014 6701 frame_0..5 # Frame 2
14    500 7069 4433 5092 4549 4898 4879 frame_0..5 # Frame 3
15    500 4297 5751 6681 frame_1_2_5 # Frame 4
16    500 5111 7030 6429 4859 5538 6000 frame_0..5 # Frame 5
17    500 6895 6255 4588 frame_1..3 # Frame 6
18    return
19
20 sub frame_0..5_7..11
21   11 servo
22   10 servo

```

#	Value
24	
23	
22	
21	
20	
19	
18	
17	
16	
15	
14	
13	
12	
11	
10	
9	
8	
7	
6	
5	
4	
3	
2	

Stop Script

Run Script

Step Script

Restart Script

 Scroll to follow script

View Compiled Code...

Save Frame 7

Apply Settings

Inicio



Pololu Maestro Contr...

Microsoft PowerPoint - [...]

09:38 p.m.
Martes
06/06/2023